



NOTES:

- 1) ALL BENDS IN CONDUIT SHALL BE MADE USING A 6" SWEEP
- 2) CONDUIT ENDS SHALL BE PLACED WITHIN 3" OF BOX CORNER
- 3) ALL CONDUIT ENDS SHALL BE SEALED USING A REMOVABLE PLUG
- 4) GROUPED METER BOXES SHALL BE PLACED WITH A 6" (MIN) AND A 5' (MAX) DISTANCE APART.
- 5) ALL CONDUITS SHALL BE DIRECTED TO ONE METER BOX WITHIN THE GROUPED SET MAKING SURE TO LEAVE ROOM FOR METER PLACEMENT.

